

HOW TO USE :

THE SYSTEM BATH PANEL

Press 'TIMER' To set required time

Press on 'L' for 'LOW' mode (to Decrease Intensity) or 'H' for 'HIGH' mode (to Increase Intensity)

Press 'STOP' to abort

'VENT' will turn 'ON' automatically to keep bathroom ventilated when other functions are turned 'OFF'

* Press 'DRY' to dry laundry (L/H mode)

* Press 'HEAT' to keep bathroom warm (L/H mode)

* Press 'FAN' to keep bathroom cool (L/H mode)

* Press 'VENT' to clear away steam and freshen air (L/H mode)

* Functions to be operated separately.