

HOW TO USE :

THE TELEVISION SET IN THE APARTMENT

The TV :



'RED' Light indicates TV is switched 'OFF'

'GREEN' Light indicates TV is switched 'ON'

TV REMOTE CONTROL

STEP 1

To Switch ON / OFF the TV

Point Remote Control at TV and
PRESS 'POWER'



To INCREASE / DECREASE VOLUME

Point Remote Control at TV and
PRESS '+ / -'



SET TOP BOX



SET TOP BOX REMOTE CONTROL



STEP 2

To select Channels, refer to Channel List provided
Point Remote Control at SET TOP BOX and
PRESS Channel Number