

Cooking Hob

Electrolux Induction Hob (EHD30010P)



A. How to use the Hob

1. Touch the on/off at '1' to start or stop the appliance
2. Touch '2', 'P' comes on in the display. Immediately touch '+' at '4', and 'A' comes on in the display, then touches '-' at '3' to the heat setting comes on
3. To prevent an accidental operation of the hob. Touch on '6' Lock/child safety device
4. Using the timer - Set the timer after the selection of the cooking zone
5. Touch '5' to turn on the timer. Press + or - to set the time in min (00 to 99 min)
6. '7' touch and go function is a pre-programmed auto switch-off time control device to keep the warm setting

Auto Switch Off Times

Heat Setting	U1-2	3-4	5	6-9
Stop After	6hr	5hr	4hr	1.5hr

Heat Settings Display

0	The cooking zone is off
1-9	The cooking zone operates
U	Keep warm setting is on The STOP + GO function is active
A	The automatic heat-up function is on
F	The induction cooking zone does not sense The cookware
E	Malfunction
H	The cooking zone is still hot (Residual Heat)
L	Lock / Child safety device is on
P	The power function is active
-	The auto switch-off is active

Cooking Time (Approximately)

Heat Setting	To cook	Time Required
U1	Keep food warm	As required
1-2	Melt butter, chocolate	5-25mins
1-2	Solidify - Omelet	10-40mins
2-3	Simmer rice, milk-based dishes, reheating cooked food	25-50mins
3-4	Steam vegetables, fish, and meals	20-45mins
4-5	Cook large quantities of food, stews, and soup	20-60mins
6-7	Gentle fry dishes, pancakes, and culets	As required
7-8	Heavy fry hash browns, loin steaks, boiling pasta	5-15mins
9	Sear meat, pot roast	As required

Note: If you encounter any problems or require more information, please inform our Concierge.